



Model 250-S and 250-DW Relief Valve

Installation & Maintenance Manual



Contents

Introduction	3
Operation	3
Installation and Start-Up	3
Servicing and Adjustment	4
Change Spring on Model 250-S	4
Service Diaphragm on Model 250-S	4
Service Valve on Model 250-S.....	4
Service Diaphragm on Model 250-DW	4
Change Weights on Model 250-DW.....	4
Service Valve on Model 250-DW	4
Model 250-S Parts List	5
Model 250-S Parts List	6
Model 250-S Relief Adjustment Range	6
Model 250-DW Parts List	7
Model 250-DW Parts List	8
Model 250-DW Relief Pressure Adjustment	9
Dimensions	10
Model 250-S	10
Model 250-DW	10
Typical Arrangement	11
Other Gases	11
Temperature Limits	11
Buried Service	11

Copyright

This document, in whole or in part, ("Document") includes confidential and proprietary information belonging to Utility Solutions Group and/or one of its subsidiaries or affiliates. Unauthorized use, reproduction, disclosure, distribution, or dissemination of this Document is strictly prohibited. No party may use, reproduce, disclose, distribute, or disseminate this Document for any purpose without express written authorization from Utility Solutions Group. Any use, reproduction, disclosure, distribution, or dissemination of this Document does not transfer title to, license, or grant any patent, copyright, trademark, or other intellectual property rights. This Document, and any copies or derivatives thereof, must be returned immediately on demand. This Document is subject to any applicable non-disclosure agreement(s). Information in this Document is subject to change without notice and does not represent a commitment on the part of Utility Solutions Group.

© 2025, Utility Solutions Group All Rights Reserved.

Utility Solutions Group
1050 Dearborn Dr.
Suite 200
Columbus, OH 43085
www.my-usg.com

Introduction

Safe practice in the transmission, distribution and utilization of gas requires a device to limit line pressure to a predetermined safe maximum, preventing overpressuring the system. Mechanical failure, accidents or foreign matter in the lines may render other types of safeguards inoperative and cause a dangerous overpressuring of the system.

Leaking bypass valves occasionally will permit pressure to build during off-peak hours. Pressure regulators with damaged valves or orifices are not able to effect a shutoff when required, thereby permitting a possibly dangerous overpressure condition.

The most reliable safeguard is a device that will open as necessary and discharge to atmosphere enough of the excess to maintain a safe pressure in the system.

The most beneficial and commonly used device is a mechanical relief valve, correctly installed at a safe dispersal point and set to discharge to atmosphere when line pressure exceeds a predetermined set-point.

Compact and easy to install, the relief valve offers an economical installation with large relieving capacity. It automatically closes when the pressure returns to normal. Many times, a small relief valve can be used advantageously with a larger relief valve. The smaller relief valve can be set for a lower discharge pressure to take care of minor pressure fluctuations without the necessity of venting a large amount of gas to atmosphere through the larger relief valve.

Operation

The operation of Utility Solutions Group Safety Relief Valves is beneficial and simple. They are installed in a vertical line with the outlet usually connected to a rigid discharge stack with a suitable protective cap. A soft-seated valve is exposed to line pressure and, under normal conditions, is held tightly closed by the force exerted by the weight or spring. When line pressure increases sufficiently to overcome the closing force, the relief valve opens to discharge gas. The relief valve automatically closes after pressure returns to normal.

Installation and Start-Up

1. Thoroughly purge inlet piping to remove dirt and debris that could damage the relief valve or impair its operation.

NOTE: Ensure that the inside of the relief valve and piping are free of dirt, foreign matter and other debris.

2. Install the relief valve. Ensure flow through the relief valve is in the correct direction. High-pressure connects to the inlet side. Be sure that shipping screens, pins, and covers are removed.

NOTE: On flanges, tighten bolts evenly. On screwed connections, apply pipe dope to male threads only.



CAUTION

It is the user's responsibility to ensure that all regulator vents and/or vent lines exhaust to a non-hazardous location away from ANY POTENTIAL sources of ignition. Where vent lines are used, it is the user's responsibility to ensure that each regulator is individually vented and that common vent lines ARE NOT used.

NOTE: The vent tubing must be 1/4-inch or larger and routed to a safe location. The outlet of the vent piping must allow for the free and unobstructed passage of air and gas and must be protected against the potentials listed in the instructions.



WARNING

The vent connection is an escape path for flammable gas and it must be located and/or piped so that potential discharge occurs in a safe area away from buildings, open flames, collection areas, arcing devices, etc.



CAUTION

Relief valves that are installed indoors or in a non-vented area must be vented to the outside. Vent piping must be routed to a non-hazardous location, away from any potential sources of ignition. For outdoor installations, it is recommended that the relief valve be installed so the potential for water or other foreign matter entering the relief valve and interfering with the proper operation is avoided.

3. Check all connections for leaks.
4. Put the relief valve into operation by very slowly opening the upstream block valve A (see illustration on Page 11).
5. Set adjusting screw (30) on 250-S for the required relief pressure. Turn it clockwise to increase the pressure and counter-clockwise to decrease it. Only make this adjustment when gas is flowing through the relief valve. After adjustment is complete, locknut (31) should be tightened firmly.
6. On the 250-DW relief valve, remove clamp ring bolts (21), cover (23) with cover cap (26), remove shipping pin (27) and install the weights, thicker ones first, over stem (18c).
7. To shut down 250-S, carefully close valve A (see illustration on Page 11). Break lock nut (31) loose. Turn adjustment screw (30) counterclockwise to depressurize.

To shut down 250-DW, remove clamp ring bolts (21), cover (23), with cover cap (26) and slowly remove weights or lift stem assembly (18) slightly to depressurize.



CAUTION

The 250-DW must be mounted in an upright position due to the weights. The 250-S can be mounted upright or upside down; however, it cannot be mounted on its side due to the lack of valve guiding.

Servicing and Adjustment

General Notes

1. Ensure both the inlet and outlet chambers of the relief valve are entirely depressurized before servicing.
2. Carefully note the location and position of disassembled parts to be certain reassembly is correct. Inspect each one carefully and replace those that are worn or damaged or otherwise unsatisfactory.
3. Use lubricants sparingly and with care to avoid exposing tacky surfaces to the gas stream. Such surfaces could cause dirt accumulation on close-clearance parts.

NOTE: Use moly or silicone type lubricants. Avoid the use of petroleum based types. An application of silicone based lubricant to the other O-rings and the tetraseals in the relief valve will also help ensure their tightness.



CAUTION

Relief valves are overpressure control devices with numerous moving parts subject to wear and are dependent upon particular operating conditions. To ensure continuous satisfactory operation, a periodic inspection schedule must be adhered to with the frequency of inspection determined by the severity of service and applicable laws and regulations.

Change Spring on Model 250-S

1. To change spring (34), close valve A (see illustration on Page 11), release adjustment screw lock nut (31), turn adjusting screw (30) counterclockwise slowly to depressurize, remove cover bolts (24), cover (23) and upper spring ferrule (32).
2. Remove spring (34) and install new spring. To install, reverse the procedure noted above.
3. Open valve A (see illustration on Page 11). Set relief valve setpoint. To increase, turn spring adjusting screw (30) clockwise, counter-clockwise to decrease. Check for leakage and reseal. Tighten adjustment screw lock nut (31) firmly. Modify badge information.

Service Diaphragm on Model 250-S

1. Complete step 1 of section "Change Spring on 250-S." Remove spring (34), lower spring ferrule (32), clamp ring bolts (21), upper diaphragm ring (20), including cover gasket (22), and stop plate (33). Also, on the 4-inch 250-S, weights (14) will be removed. Remove stem (18c), diaphragm (8), and stem assembly (18), including the diaphragm gasket (9), diaphragm (8), upper diaphragm plate (10) and diaphragm plate bolts (7).
2. Remove diaphragm plate bolts (7) from upper diaphragm plate (10), remove diaphragm (8) and diaphragm gasket (9). To install the new diaphragm and gasket, reverse the procedure noted above.

3. Open valve A (see illustration on Page 11). Set relief valve set point. To increase, turn spring adjustment screw (30) clockwise or counter-clockwise to decrease. Check for leakage and reseal. Tighten adjustment screw lock nut (31) firmly. Modify badge information.

Service Valve on Model 250-S

1. Complete step 1 of section "Service Diaphragm on 250-S." Remove valve wing (3), remove valve disc (35), clean valve holder (5), and evenly apply new valve adhesive (36) and valve disc (35). Reverse procedure.

Service Diaphragm on Model 250-DW

1. Complete step 1 of section "Change Weights on 250-DW." Remove weights (12 through 17 body per size), clamp ring bolts (21) and upper diaphragm ring (20), including cover gasket (22). Remove stem (18c), diaphragm (8), and stem assembly (18), including the diaphragm gasket (9), upper diaphragm plate (10) or (11) and diaphragm plate bolts (7).
2. Remove diaphragm plate bolts (7) from upper diaphragm plate (10) or (11). Remove diaphragm (8) and diaphragm gasket (9) and install new diaphragm and gasket. Reverse procedure noted above.
3. Open valve A, (see illustration on Page 11). Set relief valve set-point. To increase, turn spring adjustment screw clockwise or counter-clockwise to decrease. Check for leakage and reseal. Lock adjustment screw nut. Modify badge information.

Change Weights on Model 250-DW


1. To change weights (12 through 17 per body size), close valve A (see illustration on Page 11). Remove cover bolts (24) and cover (23) with cover cap (26).
2. Slowly remove weights (12 through 17 body per size) to depressurize and install new weights. Reverse procedure noted above.
3. Open valve A, (see illustration on Page 11). Set relief valve set-point. To increase, add weights, or remove weights to decrease. Check for leakage and reseal. The cover (23) with cover cap (26) should be in place during the setting of the relief valve. The cover bolts (24) should be assembled after setting the relief valve. Modify badge information.

Service Valve on Model 250-DW

1. Complete step 1 of section "Service Diaphragm on 250-DW." Remove valve wing (3), remove valve disc (6), clean valve holder (5), and evenly apply new valve adhesive (36) and valve disc. Reverse procedure.

Model 250-S Parts List

2" and 3" Model 250-S Relief Valve



2", 3", and 4" Models

Illustration Number	Description	Part Number
4	Ball Bearing	930510
7	Diaphragm Plate Bolts	910001
19	Diaphragm Plate O-ring	934008
25	Vent Cap	137-02-505-03
28	Pipe Plug	906055
30	Adjusting Screw	115-16-007-50
31	Adjustment Screw Lock Nut	922233
32	Top and Bottom Spring Ferrule	115-16-0009-50
	Spring, Aluminum	090-70-021-00
	Spring, Green	090-70-021-01
34	Spring, Yellow	090-70-021-02
	Spring, Gray	090-70-021-03
	Spring, Blue	090-70-021-04
36	Adhesive	905113

2" Model

Illustration Number	Description	Part Number
1	Body Threaded	115-16-001-50
2	Body Flanged	115-16-001-52
3	Valve Wing	115-16-012-54
5	Valve Holder	115-16-011-52
8	Diaphragm and Gasket Assembly*	115-16-350-50
9	Diaphragm Gasket	115-16-034-50
10	Upper Diaphragm Plate	115-16-010-50
	Stem Assembly	115-16-316-51
a.	Lower Diaphragm Plate	115-16-022-50
b.	Diaphragm Plate Roll Pin	901685
c.	Stem	115-16-016-50
d.	Gland	090-16-085-04
e.	Valve Roll Pin	901686
18	Upper Diaphragm Ring	115-20-275-50
21	Clamp Ring Bolts	910028
22	Cover Gasket	115-16-066-50
23	Cover	115-16-006-50
24	Cover Bolts	910036
33	Stop Plate	115-16-040-50
35	Valve Disc	115-16-017-20

* Always install with cloth side and gasket toward spring.

3" Model

Illustration Number	Description	Part Number
2	Body Flanged	115-20-001-52
3	Valve Wing	115-20-012-54
5	Valve	115-20-011-52
8	Diaphragm and Gasket Assembly*	115-16-350-50
9	Diaphragm Gasket	115-16-034-50
10	Upper Diaphragm Plate	115-16-010-50
	Stem Assembly	115-20-316-51
a.	Lower Diaphragm Plate	115-16-022-50
b.	Diaphragm Plate Roll Pin	901685
c.	Stem	115-16-016-50
d.	Gland	090-16-085-04
e.	Valve Roll Pin	901686
21	Clamp Ring Bolts	910028
22	Cover Gasket	115-16-066-50
23	Cover	115-16-006-50
24	Cover Bolts	910036
29	Upper Diaphragm Ring	115-20-275-50
33	Stop Plate	115-16-040-50
35	Valve Disc for Units with 3" Orifice	115-20-017-20

* Always install with cloth side and gasket toward spring.

Model 250-S Parts List

(Continued)

4" Model (4" Orifice)

Illustration Number	Description	Part Number
2	Body Flanged	115-22-001-52
3	Valve Wing	115-22-012-51
5	Valve	115-22-011-51
8	Diaphragm and Gasket Assembly*	115-22-350-50
9	Diaphragm Gasket	115-22-034-50
10	Upper Diaphragm Plate	115-22-010-50
14	Weights	115-16-186-50
	Stem Assembly	115-22-316-51
	a. Lower Diaphragm Plate	115-16-022-50
18	b. Diaphragm Plate Roll Pin	901685
	c. Stem	115-22-016-50
	d. Gland	090-16-085-04
	e. Valve Roll Pin	901686
21	Clamp Ring Bolts	910055
22	Cover Gasket	115-22-066-50
23	Cover	115-22-006-50
24	Cover Bolts	910062
29	Upper Diaphragm Ring	115-22-275-50
33	Stop Plate	115-22-040-50
35	Valve Disc	115-22-017-20


* Always install with cloth side and gasket toward spring.

Model 250-S Relief Adjustment Range

Spring Color	Relief Pressure Adjustment Range, psi		
	2"	3"	4"
	1 3/4" Dia.	3" Dia.	4" Dia.
Aluminum	2 - 10	1 - 4	1 - 2 1/4
Green	10 - 16	4 - 6	2 1/4 - 3 1/2
Yellow	16 - 26	6 - 10	3 1/2 - 5 1/2
Gray	26 - 40	10 - 15	5 1/2 - 7 1/2
Blue	30 - 70	15 - 30	7 1/2 - 16

Model 250-DW Parts List

2" and 3" Model 250-DW Relief Valve



2" Model

Illustration Number	Description	Part Number
1	Body Threaded	115-16-001-50
2	Body Flanged	115-16-001-52
3	Valve Wing	115-16-012-54
5	Valve Holder	115-16-011-52
6	Valve Disc	115-16-017-30
8	Diaphragm and Gasket Assembly	115-16-350-50
9	Diaphragm Gasket	115-16-034-50
10	Upper Diaphragm Plate	115-16-010-50
11	Upper Diaphragm Plate 8 oz.	115-16-010-51
	Stem Assembly	115-16-316-51
	a. Lower Diaphragm Plate	115-16-022-50
18	b. Diaphragm Plate Roll Pin	901685
	c. Stem	115-16-016-50
	d. Gland	090-16-085-04
	e. Valve Roll Pin	901686
20	Upper Diaphragm Ring	115-16-275-51
21	Clamp Ring Bolts	910028
22	Cover Gasket	115-16-066-50
23	Cover	115-16-006-50
24	Cover Bolts	910036
26	Cover Cap	115-16-074-50
27	Shipping Pin	115-16-071-00

* Always install with cloth side and gasket toward spring.

2", 3", and 4" Models

Illustration Number	Description	Part Number
4	Ball Bearing	930510
7	Diaphragm Plate Bolts	910001
12	Weights	115-16-184-50
13	Weights	115-16-185-50
14	Weights	115-16-186-50
19	Diaphragm Plate O-ring	934008
25	Vent Cap	137-02-505-03
28	Pipe Plug	906055
36	Adhesive	905113

Model 250-DW Parts List

(Continued)

3" Model (2 1/2" and 3" Orifice)

Illustration Number	Description	Part Number
2	Body Flanged	115-20-001-52
	Body Flanged, for Units with 2 1/2" Orifice	115-20-001-53
3	Valve Wing	115-20-012-54
	Valve Wing, for Units with 2 1/2" Orifice	115-20-012-56
5	Valve	115-20-011-52
	Valve, for Units with 2 1/2" Orifice	115-20-011-53
6	Valve Disc	115-20-017-30
	Valve Disc, for Units with 2 1/2" Orifice	115-20-017-31
8	Diaphragm and Gasket Assembly*	115-16-350-50
9	Diaphragm Gasket	115-16-034-50
10	Upper Diaphragm Plate	115-16-010-50
14	Weights	115-16-186-50
18	Stem Assembly	115-20-316-51
	a. Lower Diaphragm Plate	115-16-022-50
	b. Diaphragm Plate Roll Pin	901685
	c. Stem	115-20-016-50
	d. Gland	090-16-085-04
20	e. Valve Roll Pin	901686
	Upper Diaphragm Ring	115-16-275-51
	Clamp Ring Bolts	910028
	Cover Gasket	115-16-066-50
	Cover	115-16-006-50
22	Cover Bolts	910036
23	Cover Cap	115-20-074-50
24	Shipping Pin	115-20-071-00

* Always install with cloth side and gasket toward spring.

4" Model (4" Orifice)

Illustration Number	Description	Part Number
2	Body Flanged	115-22-001-52
3	Valve Wing	115-22-012-51
5	Valve	115-22-011-51
6	Valve Disc	115-22-017-30
8	Diaphragm and Gasket Assembly*	115-22-350-50
9	Diaphragm Gasket	115-22-034-50
10	Upper Diaphragm Plate	115-22-010-50
15	Weights	115-22-184-50
16	Weights	115-22-185-50
17	Weights	115-22-186-50
18	Stem Assembly	115-22-316-51
	a. Lower Diaphragm Plate	115-16-022-50
	b. Diaphragm Plate Roll Pin	901685
	c. Stem	115-22-016-50
	d. Gland	090-16-085-04
20	e. Valve Roll Pin	901686
	Upper Diaphragm Ring	115-16-275-51
	Clamp Ring Bolts	910028
	Cover Gasket	115-16-066-50
	Cover	115-16-006-50
22	Cover Bolts	910036
23	Cover Cap	115-16-074-50
27	Shipping Pin	115-22-071-00


* Always install with cloth side and gasket toward spring.

Model 250-DW Relief Pressure Adjustment

Size	Valve Diameter	Relief Pressure Adjustment Range	Minimum Relief Pressure Without Weights	Adjustment Weights		Maximum Number of Weights	
				Size	Will Increase Relief Pressure		
2"	1 3/4"	8 to 6 ounces	15 ounces (8 ounces Special)	3 3/4" x 1"	12 ounces	7 - 1"	
				3" x 1/2"	6 ounces		
				3" x 1/4"	3 ounces		
	3"	8 to 36 ounces		3 3/4" x 1"	4 ounces		
				3" x 1/2"	2 ounces		
				3" x 1/4"	1 ounces		
3"	2 1/2"	11 to 50 ounces		3 3/4" x 1"	6 ounces	7 - 1"	
				3" x 1/2"	3 ounces		
				3" x 1/4"	1 1/2 ounces		
	4"	8 to 32 ounces		3" x 1/2"	1 ounces	Use these weights first, immediately above diaphragm	
				3" x 1/4"	1/2 ounces		
				3 3/4" x 1"	4 ounces		
				3" x 1/2"	2 ounces		
				3" x 1/4"	1 ounces		


Dimensions

Model 250-S



GIM1450B-015

Model 250-DW




GIM1450B-020

Size	A	B	E	Weight
2" NPT				
2" Flanged	19 1/2"	3 1/4"	3 1/4"	30
		4 1/4"	4 1/4"	40
3"	20 3/4"	5"	5"	65
4"	22 1/4"	6"	6"	110

Size	A	B	E	Weight
2" NPT				
2" Flanged	16 3/4"	3 1/4"	3 1/4"	30
		4 1/4"	4 1/4"	40
3"	18 1/4"	5"	5"	65
4"	20"	6"	6"	110

Typical Arrangement

(Indoor or Outdoor Installation)



Other Gases

Model 250-DW and 250-S Relief Valves are mainly used on natural gas services; however, this relief valve will perform equally well on other gases. When using Model 250-DW and 250-S Relief Valves on other gases, the relief valve capacities must be adjusted using the following correction factors:

Type of Gas	Correction Factor
Air (Specific Gravity 1.0)	0.77
Propane (Specific Gravity 1.53)	0.63
1350 BTU Propane-Air Mix (Specific Gravity 1.20)	0.71
Nitrogen (Specific Gravity 0.97)	0.79
Dry Carbon Dioxide (Specific Gravity 1.52)	0.63

Temperature Limits

The Model 250-S and 250-DW Relief Valves can be used for flowing temperatures from -20°F to 150°F.

Buried Service

The Model 250-S and 250-DW Relief Valves are not recommended for buried service.

For other non-corrosive gases, use the following formula:

$$\text{Correction factor} = \sqrt{\frac{0.60}{\text{Specific gravity of the gas}}}$$

For use with gases not listed above, please contact your Utility Solutions Group Representative or Authorized Distributor for recommendations.



UTILITY SOLUTIONS GROUP

<https://my-usg.com/>

USG Headquarters

1050 Dearborn Dr.
Suite 200
Columbus, OH 43085

Support@my-usg.com
614-704-5650
888-456-6060 (International)